



## EASY INSTALLATION STEPS

### 1 Layout Posts

Plan post orientation, paying attention to the end and corner posts.  
Corner: recommended to screw into 2x4 spacer to avoid end splitting.

### 2 Set Posts

Fence post should be set approximately 6 to 8 feet apart, depending on fence type and terrain. Set the corner or end posts first, then stretch a line to align all posts in between. Mark hole positions. We recommend setting the posts in 8 inch diameter holes. Set posts a minimum 24" deep in concrete. Use a level to ensure posts are straight.

### 3 Install Rails

The hole pattern on Z Post makes framing easy! Simply screw the rails into the post flanges with 1 1/2" galvanized or coated screws. A minimum of 2 screws are recommended per joint.

### 4 Install Boards

Finish the fence off by covering the exposed side of the Z Post with a cover board.

*\*Always consult your local building guidelines*